

1/10th 4WD Nitro Power R/C Monster Truck

Specifications:

LENGTH	WIDTH	HEIGHT	WHEEL BASE	DRIVE SYSTEM	GROUND CLEARANCE	DIAMETER OF WHEEL	WIDTH OF WHEEL	GEAR RATIO	THROTTLE SERVO	STEERING SERVO
420mm	330mm	185mm	275mm	4WD Shaft Drive	30mm	120mm	60mm	1:13.34	3kg	6kg

Spare Part


06056-Chassis	08048-Front Upper Arm	08049-Front Lower Arm	08050-Rear Lower Arm	08051-Rear Upper Arm
06055-Front Upper Arm Holder	08058-Shock Absorber	08012-Shock Tower	08007-Body Post	08002-Front Bumper
08062-Rear Bumper	08030-Front Shock Tower Holder	08031-Rear Shock Tower Holder	08028-Front Bumper Post	08032-Bumper Spring
02165-Steering Hub (Left/Right)	02166-Rear Wheel Hub Carrier (Left/Right)	06045-Front Gear Box Housing	06046-Rear Gear Box Housing	06063-Front Gear Box Complete
06064-Rear Gear Box Complete	02074-Steering Ackerman Joint	02075-Steering Arm Complete B	08425-Steering Assembly A	02110-Radio Tray
02046-Radio Tray Post A	02047-Radio Tray Post B	08008-Wheel Rims	08043-Tires+Insert Sponge	08071-Wheels Complete

Spare Part

08064-Wheel Axle	08065-Wheel Hex.	02173-Suspension Arm Pad	02070-Battery Compartment	02111-Battery Cover
02072-Servo Arm	02155-Chargeable Battery Pack (6V 1100mA)	02065-Flywheel Pilot Post	06016-Servo Link	08042-Front/Rear Link
08004-Front/Rear Diff Mount	08063-Diff. Gear Complete	02024-Diff. Main Gear Complete	08074-Crown Gear (38T) (Copper infiltration)	02030-Drive Gear
02066-Diff. Pinions+Pin	08013-Diff. Gear Complete	08033-Diff. Gear 7(35T)/(17T)	08067-Diff. Gear 2(17T)/6(27T)	20726-Diff. Gear 3(27T)
02068-Engine Flywheel	02107-Clutch Bell (Single Gear)	02016-Universal Joint Cup B/Set Screws*4	02032-Universal Joint Cup C	02034-Universal Joint Cup A/Grub Hex. Screw 4*4
08059-Dogbone 89.5mm	08060-Dogbone 77mm	08061-Dogbone 63mm	02036-3*44mm Front Suspension Arm Pin A	02063-3*54mm Rear Suspension Arm Pin A
08068-Rear Lower Suspension Arm Round Pin Bφ3*21mm	08069-Front Lower Suspension Arm Round Pin Bφ3*43mm	08057-Diff. Post	08018-First Step Axle	08022-Second Step Axle

Upgradable Optionals

122203-Aluminum Radio Tray Mount/Post+Cap Head Machine Screw 3*10*4P+3*8*4P+Flat Head Machine Screw 3*10*4P	122205-Aluminum Engine Mount	122206-Aluminum Lightweight Flywheel	102009-Aluminum Exhaust Pipe	122042-Aluminum Wheel Hex Mount
122048-Aluminum Locknut M3	122049-Aluminum Locknut M4	122211-Aluminum Steering Hub(L/R)+Ball Head Nut 4P	122212-Aluminum Rear Hub Carrier (L/R)+Ball Head Nut	122227-Aluminum Suspension Arm Reinforcement Bracket
122240-Aluminum Ackerman Plate	122257-Aluminum Steering Servo Saver Complete	122259-Aluminum Fuel Tank Cover+Cap Head Machine Screw 2.6*4*2P	122273-Aluminum Clutch Shoe	122275-Aluminum Gear Box/Flat Head Machine Screw 3*10*4P+Cap Head Machine Screw 3*15*2P+3*10*2P+Round Head Machine Screw 3*12*2P
166617-Aluminum Front Rear & Servo Link/Flat Head Machine Screw 3*14*4P/Nut M3*4P	166664-Aluminum Battery Cover	188004-Aluminum Shock Absorber	188015-Universal Drive Joint	188865-Aluminum Compact Radio/Fuel Tank Tray
188818-Aluminum Front Upper Arm/M5 Ball Head Screw 2P	188819-Aluminum Front Lower Arm/Cap Head Machine Screw 3*12*4P/Grub Screw M4*6*2P/M5 Ball Head Screw 2P	188820-Aluminum Rear Upper Arm	188821-Aluminum Rear Lower Arm/Cap Head Machine Screw 3*12*4P/Grub Screw M4*6*2P/M5 Ball Head Screw 4P	188822-Aluminum Shock Tower+Cap Head Machine Screw M3*12mm*2P
188831-Aluminum Front Upper Arm Mount/Cap Head Machine Screw	188835-Aluminum Front Brace+Cap Head Machine Screw 3*8*6P	188836-Aluminum Rear Brace+Cap Head Machine Screw 3*8*4P/3*10*2P	188837-Aluminum Body Post	108839-Aluminum Wheel Rim
188870-Aluminum Centre Diff Mount+Flat Head Machine Screw 3*10*8P	02031A-Polished Aluminum Manifold +Pad	02156-Aluminum Fuel Filter	04104-Aluminum Capped Air Filter Cover Optional Use	80237-Anodized Aluminum Servo Arms



Spare Part

08026-Third Step Axle	08027-Pin 2*10mm	02004-Fuel Tank	02058-Fuel Tube	02172-Exhaust Pipe Tubing
02026-Exhaust Pipe	02028-Air Filter W/Sponge	02031-Exhaust Manifold	02048-Clutch Shoe(w/Spring) 02048(M) 02048(F)	02049-Engine Holder W/Column Head Screws M3*10
02011-Handle	02174-Throttle/Brake Assembly	02059-Exhaust Pipe Holder w/Flat Screw & Nut	02044-Disc Brake	02039-Differential Box+Seals+Washers
08016-Brake Cam Mount	08034-Brake Pads	08017-Adjustable Nut	16602-Switch	03027-Charger/Battery Wire Connector
02103-Zip Tie	02171-Sway Arm Adjuster	02153-Ball Head Nut	02152-M5 Ball Head Screw	02038-Ball Head Screw
08021-Shock Ball Head 1	08072-Shock Ball Head 2	06007-Shock Ball Head C	02164-Ball Head Cap	02101-Steering Bushing
02102-Nylon Nut M3	02055-Nylon Nut M4	02037-E-Clip (φ7.4 φ2.5 φ2.3)	02057-Antenna Pipe	02053-Body Clip

Spare Part

02501-Washer 8*5.2*0.5	02078-O-Ring	02079-Oil Bearing φ15*φ10*4	02080-Oil Bearing φ5*φ10*4	02138-Ball Bearing φ15*φ10*4
02139-Ball Bearing φ10*φ5*4	02098-M3*4 Grub Hex. Screw	02099-Grub Hex. Screw M4*4	02181-Cap Head Self-Tapping Screw 3*15 10P	02083-Cap Head Self-Tapping Screw 3*12 6P
02081-Cap Head Self-Tapping Screw 3*8 6P	02082-Cap Head Self-Tapping Screw 3*10 10P	02084-TT3*20 BH Screw 4P	02176-3*12 Cap Head Machine Screw 4P	02096-3*10 Cap Head Machine Screw 6P
18243-3*8 Cap Head Machine Screw 10P	02097-3*14 Cap Head Machine Screw 6P	02194-BT.2.6*12 BH Screw 4P	02085-Round Head Self-Tapping Screw 2*8 8P	02086-Round Head Self-Tapping Screw 2*10 10P
01083-Round Head Machine Screw 3*11 6P	81220-5-Countersunk Cross Head Self-Tapping Screw 3*14 4P	02087-Countersunk Cross Head Self-Tapping Screw 3*10 15P	02088-Countersunk Cross Head Self-Tapping Screw 3*14 13P	02092-ISO 3*10 Screw 8P
02090-TPE3*25FH Screw 4P	02180-Flat Head Self-Tapping Screw 3*16 10P	02093-M3*10 Column Head Hex. Screw 10P	02095-M3*8 Column Head Hex. Screw 4P	02094-M3*30 Column Head Hex. Screw 4P
08024-Discal Screw M3*11 8P	02060-Engine 16CXP/18CXP	02200-New Engine 18CXP/20CXP	11016-Pull Starter	

Monster Truck Exploded View

